

Blueair believes in cleaner indoor air for everyone. Removing air impurities down to the tiniest particle requires a deep commitment to continuous innovation and a greener global environment. Our fresh air solutions are not only inventive, but extremely effective and eco-friendly. At Blueair we believe that clean air is a human right.

www.blueair.com/airpod

Blueair Inc.

17 North State Street, Suite 1830
Chicago, IL 60602
1.888.blueair (1.888.258.3247)
Fax 312.727.1153
www.blueair.com


Blueair AB


Danderydsgatan 11
SE-114 Stockholm, Sweden
Tel. +46-8-679 45 00, Fax +46-8-679 45 45
info@blueair.se
www.blueair.se



AIRPOD

Instruction Manual






Mounting and replacing filter

Filters should be replaced every ??? month or when needed. For more information about our filters/filter programs/extended warranties visit: www.blueair.com/airpod.

Operating the AirPod

Variable speed control. On/Off switch function in it's highest position.



Power supply

Connect the AC/DC 12V adpater to a socket and connect the 12 V plug to the connection on the back of the AirPod.

